# **CpE 100 Hands On Assignment 1**

From: Fall 2017, Section 1001 (Dr. Harris)

# **Hands-on Exercises [80 pts total]**

#### 1. Introduction

In this portion of this assignment, you will use the Quartus II Web Edition v13.1 software, a powerful commercial suite that will enable you to design, simulate, and test digital circuits. You can use this software either:

- 1. Installed the software on your own laptop or computer (see Homework 2), or
- 2. Using the PCs located in the Electrical and Computer Engineering Laboratories, located in TBE B-350 or TBE B-311. For this, you must have an ACE account.

Skim through all of these instructions and carefully read the **What to Turn In** section (Section 3) before beginning this portion of the homework.

You will complete the following steps to:

- Step 1. Design a Boolean function
- **Step 2.** Sketch a gate-level implementation of the function.
- Step 3. Enter your design in Quartus II
- Step 4. Simulate your design using ModelSim
- Step 5. Test your design on the DE0-CV board

Here are instructions again for installing the Quartus II software on your own PC if you didn't so last time but would still like to.

## Step 0. Optionally install the Quartus II software

If you would like to install the Quartus II v13.1 software on your own laptop or computer, follow these instructions. Otherwise skip to Step 1.

Note that a newer version of the software exists, however, you will install version 13.1 to be consistent with the version in the ECE labs.

Browse to: <a href="https://dl.altera.com/13.1/?edition=web">https://dl.altera.com/13.1/?edition=web</a>. Select the operating system of choice (Windows or Linux) and leave the **Select All** box selected, as shown in Figure 1. Then click

## on Download Selected Files.




Figure 1. Quartus II Web Edition v13.1 download window

You will now be directed to the myAltera login page. Select **Create Your myAltera Account**, as shown in Figure 2, enter your email address and click on **Create Account**. Follow the steps to create a free account.




Figure 2. Create a myAltera account

After you have successfully created an account and logged in, the download will begin, as shown in Figure 3. If for some reason the download does not begin, you can click on **Show direct links** to download the individual files manually. Depending on your internet connection speed, downloading the files can take a while – so if you decide to install the software on your own computer, **don't do it at the last minute!** 




Figure 3. Downloading Quartus II installation files

After completing the download of all of the files, click on the QuartusSetupWeb-13.1.0.162.exe file to install the software.

## Step 1. Design a Boolean function

Now you will design a digital circuit that implements the following function of four inputs, A, B, and C.

The output **Y** is TRUE if (and only if):

- A and B are TRUE or
- B and C are TRUE or
- A and B are TRUE and C is FALSE or
- A and B are FALSE and C is TRUE

Write a Boolean equation for Y in terms of the inputs A, B, and C. Then use Boolean algebra to minimize the expression. Express your final answer in minimized sum-of-products (SOP) form.

Now complete a truth table for the function Y.

# Step 2. Sketch a gate-level implementation of the majority function.

You will now turn the expression (minimized SOP form) into a circuit consisting of AND, OR, and NOT gates. Clearly label the inputs and output on your schematic.

# Step 3. Enter your design in Quartus II

Now that you know how to produce the Y output using simple logic gates, you will enter your schematic into the Quartus II software and test it in simulation to see if it works the way you expected it to. The Quartus II software is a powerful and popular commercial suite of applications used by hardware designers.

First, you will learn how to start a new project. Start the Quartus II v13.1 software from the Start menu. Choose Quartus II (click on the Start button, then type in "Quartus II 13.1" in the search box to find the application), as shown in Figure 4.




Figure 4. Start Quartus II 13.1

A window will pop up asking if you want to buy the software, simply click on **Run the Quartus II software**, as shown in Figure 5. Then click OK.




Figure 5. Run the Quartus II software

In the Quartus II Window, click on **File**  $\rightarrow$  **New Project Wizard**. In the New Project Wizard, click Next. Then set the working directory to a convenient place (that you will be able to find again). Name the project **hw5\_xx**, where "xx" are your initials. Make sure there are no spaces or unusual characters in the path or file name; the tools may complain or silently misbehave if it has trouble with the file name.

You are now on the **Family & Device Settings** page to select a chip. You will be using the Altera DE0-CV development board, which contains a Cyclone V 5CEBA4F23C7 FPGA. Set the family to Cyclone V, as shown in Figure 6. Scroll down and select the device (**5CEBA4F23C7**) from the list of Available Devices. (You can also type that value in the

Name filter box to make it easier to find.) Highlight the device under Available devices, and click **Next**. Then click **Finish** to create your new project.



Figure 6. Set FPGA target

The Quartus II window will open in a moment. You may wish to maximize the window. You will see three main panes, as shown in Figure 5 (and can bring them up from the View → Utility Windows menu if you accidentally close one):

- **Project Navigator:** Lists the current project's sources file and the chip in use.
- Tasks: Lists the processes to perform on the source selected in the Sources pane. For example, we will use this pane later to download a circuit design onto the Cyclone V FPGA.
- **Messages:** Lists the output of current processes, errors, and warning at the bottom of the screen. Keep an eye on these messages; important warnings appear here.




Figure 7. Quartus II window

We will describe some of the options for using these resources, but we also recommend exploring these resources on your own to become familiar with Quartus' capabilities. Use the Help menu for additional information.

Quartus has a basic and strikingly ugly schematic editor that we will use. It is not particularly sophisticated because designers today primarily use hardware description languages (HDLs) instead of schematics. However, understanding schematics is an important first step to mastering HDLs.

Create a new schematic by choosing **File** → **New** and selecting **Block Diagram** / **Schematic File** (as shown in Figure 8), and click OK. A new schematic window named Block1.bdf will appear.




Figure 8. New Block Diagram/Schematic File

First, you will place the logic gates from your design. **Click on the Symbol Tool** icon (the button shaped like an AND gate) (see Figure 9).




Figure 9. Add gates to schematic

In the small window that opens, expand the Altera library by clicking the arrow  $\triangleright$  next to it. Then look under primitives  $\rightarrow$  logic and choose **and2**, as shown in Figure 10.



Figure 10. Adding gates from the Altera library

Click OK, then click again on the schematic window to place multiple 2-input AND gates, as shown in Figure 11. Leave some room between the gates to draw a wire later. Press the Esc key or right click and choose Cancel to get out of the placement mode. Place a single multiple-input OR gate as needed as well using the same method. Add other gates (NOT, etc.) as needed.




Figure 11. Schematic entry

Click on the Symbol Tool again and choose **primitives**  $\rightarrow$  **pin**  $\rightarrow$  **input**. Place three input pins on the left side. Leave some space between the pins and the gates so that you can wire them together later. Then choose an output pin and place it on the right. Double click on one of the input pins and change its name to **A**. Leave the default value unchanged at VCC. Rename the other inputs to **B** and **C**. Rename the output to **Y**.

Use the Orthogonal Node Tool ( ) to wire the gates together. Click and drag to connect the pins to gates and the two gates together. As you get close to a pin or gate input/output, it will highlight its port.

If you need to make corrections, use the Selection Tool to grab and move gates or wires. Zoom in and out by using the View menu or holding the Ctrl key while turning the mouse wheel. Use delete and undo (Ctrl-z) as necessary.

Choose **File** → **Save** and save your schematic as **hw3\_xx.bdf**, where "xx" are your initials.

Select the Files tab in the Project Navigator pane to see a list of files of the project (presently just hw3\_xx.bdf). If you need to reopen the file later, double-click on it here.

To check your design, click on Start Compilation in the Task pane (or, alternatively, choose: Processing → Start Compilation). You'll see a compilation report indicating 4 pins (i.e., 3 inputs and 1 output) and 1 logic element. Review the warnings and errors shown in the messages pane (see Figure 12).

```
All O A A CONTROLL OF CONTROLL
```

Figure 12. Messages pane

You may get the following warnings that are harmless:

```
Warning (292013): Feature LogicLock is only available with a valid subscription license. You can purchase a software subscription to gain full access to this feature.

Warning (15714): Some pins have incomplete I/O assignments. Refer to the I/O Assignment Warnings report for details

Critical Warning (169085): No exact pin location assignment(s) for 4 pins of 4 total pins

etc.
```

Browse the warnings to make sure there are no mistakes. For example, the following warnings indicate that one of the gates is missing an input connection.

```
Error (275044): Port "IN" of type NOT of instance "inst3" is missing source signal

Error (12153): Can't elaborate top-level user hierarchy

Error: Quartus II 64-Bit Analysis & Synthesis was unsuccessful. 2 errors, 1 warning

Error (293001): Quartus II Full Compilation was unsuccessful. 4 errors, 1 warning
```

After you have compiled your design without errors, you are ready to test your circuit in simulation.

# Step 4. Simulate your design using ModelSim

One motivation for drawing your full adder schematic in Quartus II is that you can now use software to simulate the operation of the circuit. This allows us to verify the correctness of your design before actually building the circuit in hardware. In this part of the assignment, you will simulate the design using **ModelSim-Altera 10.1d.** This software comes with the Quartus II 13.1 software.

ModelSim expects a description of a circuit in a hardware description language (HDL) such as Verilog. To convert your schematic to Verilog, open the schematic (available in the Project Navigator pane under the Files tab) and choose **File** → **Create** / **Update** → **Create HDL Design File for Current File**. Choose **Verilog HDL**, and click **OK**. Your file should be written to hw5\_xx.v. Watch for and correct any warnings or errors that arise.

Now fire up **ModelSim-Altera 10.1d**. Open ModelSim (from the Windows start menu: Start → ModelSim-Altera 10.1d to find the application). Maximize the ModelSim window when it opens. If prompted, you may wish to associate file types with ModelSim but do not want to use Jumpstart.

Choose **File**  $\rightarrow$  **New**  $\rightarrow$  **Project**. Name the project hw5\_xx and put it in the directory where you are working (e.g. hw5\_xx), as shown in **Figure 13**. Accept the default library name of "work." Click **OK**.




Figure 13. Create ModelSim Project

Then click the **Add Existing File** icon and add hw5\_xx.v (browse to your Quartus II project to find it). Click **OK**, then **Close**.

You should see hw5\_xx.v in the ModelSim project pane. Double-click on it to view it. The file should list the inputs and outputs and the wires (using default names if you didn't name them yourself). It should then have a series of "assign" statements describing the gates. & indicates AND. | indicates OR. ^ indicates XOR. ~ indicates NOT. Chapter 4 of the

textbook describes SystemVerilog (the newest version of Verilog) if you're interested to learn more about it.

Choose **Compile**  $\rightarrow$  **Compile All** to compile the Verilog code into a form that ModelSim can simulate. Watch for and correct errors in the transcript pane. Then choose **Simulate**  $\rightarrow$  **Start Simulation**. Click on **work** to expand the library, and choose **hw5\_xx** as your module to simulate. Click OK.

You may get a message: Error: invalid command name "". Click Skip Messages to ignore it.

ModelSim will open more panes including sim and Objects panes that help you select signals for the waveform viewer. In the **sim** pane, be sure hw3\_xx is selected. In the **Objects** pane, you'll see all the inputs, outputs, and internal wires. Select the inputs (A, B, and C) and the output Y using click and ctrl-click, as shown in Figure 14.




Figure 14. Selecting signals

Then right-click and choose  $Add \rightarrow To Wave \rightarrow Selected Signals$ . A waveform ("Wave") pane will pop up with the signals.

Now it is time to apply the inputs. In the transcript pane at the bottom, type

force A 0
force B 0
force C 0

Press return after each line. These signals are case sensistive, so **don't** type: force a 0, etc. This will set all three inputs to 0 and simulate for 100 ns. (Note that Verilog is case-sensitive; "A" and "a" are different.) You should see all the inputs and outputs with values of "0" (a low level) in the Wave pane, as shown in Figure 15.



Figure 15. ModelSim simulation waveform

Next, raise C:

force C 1 run 100

You'll see C rise. (This gives the ABC = 001 combination). If your design is correct, Y will rise to 1.

Continue with the six other patterns of inputs to check your truth table.

If you have errors, you may want to look at the internal nodes to track down the problem – i.e., add them to your waveform. Fix the schematic, then regenerate the Verilog file (all in Quartus). Then in ModelSim, recompile and restart the simulation.

If the waveform is not visible, choose  $View \rightarrow Wave$  from the menu. Click the "Zoom Full" icon in the taskbar to see the whole waveform of the simulation results. You can also use

the "Zoom In" and "Zoom Out" icons: Late. Check and see that the output value (Y) is correct. If not, go back and fix your schematic and resimulate. When the output values are correct, you have a working majority circuit!

Save an image of the waveform. Make sure the entire waveform is visible and that only the signals, A, B, C, and Y are visible (ordered from top to bottom). Also make sure you have tested the sequence in counting order (i.e., ABC go in this order: 000, 001, 010, 011, 100, 101, 110, 111). Select **File**  $\rightarrow$  **Export**  $\rightarrow$  **Image...**, and save the file. If needed, you can also print the waveform. Choose **File**  $\rightarrow$  **Print** to print a copy of your waveforms to turn in. You can choose the start and end times in the bottom right of the print dialog box. Now close the ModelSim project.

#### Step 5. Test your design on the DE0-CV board

You are now going to download your design onto the FPGA. If you are in CpE 100L, you received the DE0-CV board in lab. Otherwise, you received this in class. The board has an

FPGA (labeled CycloneV) in the middle of the board as well as 10 switches (on the bottom of the board) and 10 LEDs just above the switches (see Figure 16). The FPGA will configure itself to implement the gates of your design and the FPGA's pins are connected to the LEDs and switches.




Figure 16. DE0-CV board (image courtesy Terasic Inc.)

You will map the inputs A, B, and C to the three right-most switches (called SW[0], SW[1], and SW[2], from right to left. The output Y will connect to the right-most LED (light emitting diode), called LEDR[0].

So, before downloading your design to the board, you need to rename inputs A, B, and C, SW[0], SW[1], and SW[2], respectively. Rename the output Y to LEDR[0]. Open up the schematic in Quartus II and rename the signals.

You will now add a pin assignment file to your Quartus II project. This file defines which pins of the FPGA are connected to which signals. Download this file from <u>Altera's University site</u>: it is called **de0\_cv.qsf** [<u>link</u>]. Place it in a convenient location (for example, your Quartus II project folder).

In Quartus II, click on Assignments  $\rightarrow$  Import Assignments... (see Figure 17).




Figure 17. Importing pin assignments

Now click on the browse button (...) as shown in Figure 18.




Figure 18. Import Assignments

Browse to where you placed **de0\_cv.qsf** (Quartus Settings File). You don't need to keep a backup of the existing pin assignments, so **uncheck** the box next to **Copy existing assignments into Project1...** and click **OK**, as shown in Figure 19.




Figure 19. Selecting the .qsf (pin assignment) file

### Now recompile your design.

After completing these steps, you are ready to download your design to the DE0-CV FPGA board. First, **connect and turn on the DE0-CV board** to your computer. Connect the USB cable between your computer and the board, and connect the power cable to an outlet. Press the red power button once to turn on the board. You should see the LEDs turning on in patterns and hex values 0-f displaying on the 7-segment displays just above the LEDs.

Now click on **Tools** → **Programmer** in Quartus II (see Figure 20).




Figure 20. Programming the DE2-115 board with the MIPSfpga system

The Programmer window will open (see Figure 21).




Figure 21. Programmer window

Now click on **Add File...** (see Figure 22).




Figure 22. Add File...

Click on the output\_files folder located in your project directory and double-click on **lab5\_xx.sof** (see Figure 23).




Figure 23. Select programming file

The lab05\_xx.sof (SRAM Object File) contains the information to configure the Cyclone V FPGA on the DE0-CV board so that it implements your design. Now click on **Start**, which will configure the FPGA (see Figure 25).

**Hints:** If you are having problems downloading to the board click on Hardware Setup... in the top left of the programming window.




Figure 24. Hardware Setup...

Then click on USB-Blaster [USB-0] under Currently selected hardware (see Figure 25). Note that number may differ – i.e., USB-1, etc. If no USB-Blaster option is available, the driver is not installed, or the cable is not connected to your computer, etc.




Figure 25. Setting Currently selected hardware

After clicking the Start button, wait a few seconds and your design will be downloaded onto the DE0-CV board. Now test all combinations of the inputs and see what the output (rightmost LED) does. For example, for the ABC = 000 combination, all the switches should be in the down position. Check and make sure that the right-most LED does not light up (i.e., the output is 0). Then switch C to 1 (that is, flip the right-most switch up). This will now test the 001 combination: the LED should light up (i.e., the output should be 1). And so on. Test all combinations of inputs and make sure the output matches your desired truth table.

### 3. What to Turn In for the Hands-on Exercises

Turn in the following for the hands-on portion of the exercises:

- 1. [5 pts] A **minimized SOP form** of your equation for Y.
- 2. [5 pts] A **truth table** showing the Y output.
- 3. [5 pts] A **hand sketch** of your circuit schematic remember to make it neat and readable.
- 4. [20 pts] A print out of the **Quartus II schematic** of the majority circuit.
- 5. A print out of the **ModelSim simulation** of the circuit. Make sure that you test the circuit in counting order (i.e., ABC = 000, 001, 010, 011, ... 111). Make sure that you list your signals in the following order (top to bottom): A, B, C, Y.
- 6. [20 pts] A **picture of the DE0-CV board** (in black-and-white) showing the ABC = 011 combination.
- 7. [10 pts] A statement confirming that the **circuit worked** in hardware (i.e., on the FPGA board) for all combinations of inputs.
- 8. [10 pts] A brief paragraph (2-4 sentences) saying **what you learned** by doing this hands-on work.